

DPM2000 : OPERATOR'S MANUAL CORRECTIONS: TN # 24.0

The RIP Operator's Manual (ONS-7528) indicates that an acceptable method of exiting the RIP is using the minimize window.

This is an error! Minimizing the RIP window to the Local and QuickPlate menus can cause serious DPM malfunctions. **Always exit the RIP by closing it.**

Please modify your manuals so that on Page 4-10, step 2 is deleted.